



**Yale®**

(GB) Installation - (IT) Installazione - (DE) Installation - (NO) Installasjon - (SE) Installation - (DK) Installation.



(IT) Associazione/test - (DE) Verbinden/Testen -  
(NO) Tilkobling/Test - (SE) Para/Testa - (DK) Tilslut/test

SR-SD



1.5V AAA



**(GB)** Please see your Yale Smartphone Alarm System Instruction manual for the following: Adding this component to your Alarm, Changing the batteries, Troubleshooting.

**(IT)** Si prega di consultare il manuale istruzioni dell'allarme Yale Smartphone Alarm per le seguenti operazioni: Aggiungere questo componente al vostro allarme, Installazione, Sostituzione batterie, Risoluzione dei problemi.

**(DE)** Bitte beachten Sie Ihren Yale Smartphone Alarm-System Bedienungsanleitung für folgende: Das Hinzufügen dieser Tür / Fenster-Detektor, um Ihren Alarm, Installieren, Batteriewechsel, Fehlersuche.

**(NO)** Vi refererer til den medfølgende brukermanualen av Yale Smartphone Alarm systemet for følgende informasjon: Legge til tilleggsutstyr, Montere enheter, Bytte batterier, Problemløsning.

**(SE)** För nedanstående hänvisas till Yale Smartphone Alarm system manualen: Lägga till en komponent till ditt larmsystem, Installation, Batteribyte, Felsökning.

**(DK)** Se hovedmanualen til Yale Smartphone Alarm System, som indeholder vejledning i flg.: tilføj komponenter, installation, batteriskift, fejlfinding.


(GB) Environment - (IT) Ambiente - (DE) Umgebung - (NO) Miljø - (SE) Miljö - (DK) Miljø.



**Housings** ABS/polycarbonate

(IT) "Involucro di TUTTI i dispositivi ABS/polycarbonato"  
(DE) Alle Geräte , Gehäuse ABS Polycarbonat  
(NO) ALLE komponenter. Deksel av ABS/polykarbonat  
(SE) Alla komponenter Plasthölje ABS/Polycarbonat  
(DK) "Alle komponenter ABS/polycarbonat"

-10 °C to 40 °C



**RoHS**

An ASSAABLOY Group brand

**ASSA ABLOY**


SR-SD-MI-v04






(GB) How does it work - (IT) Come funziona - (DE) Wie es funktioniert -  
 (NO) Hvordan virker det - (SE) Hur fungerar det - (DK) Hvordan virker det



Pair and test planned location for stable radio performance (1)




i





(1) (IT) Associazione nuovo dispositivo. Eseguì un test della posizione programmata dei componenti -  
 (DE) Verbinden neuer Geräte. Testen Sie Ihren gewählten Standort - (NO) Tilkobling av ekstrastyr.  
 Test for stabile trådløse signaler - (SE) Para in nytt tillbehör. Test radiostyrka - (DK) Tilslut ekstrastyr.  
 Test for stabil trådløs forbindelse

i




Testing Every month (3)



i

Recalibrating (4)



(2) (IT) Premere alarm OFF - (DE) Drücken Sie Alarm AUS - (NO) Deaktiver alarmen - (SE) Tryck alarm av - (DK) Sluk alarm.  
 (3) (IT) Test ogni mese - (DE) Jeden Monat Testing - (NO) Test hver måned - (SE) Testa varje månad - (DK) Test hver måned  
 (4) (IT) Calibrazione - (DE) Neukalibrierung - (NO) Rekalibrering - (SE) Kalibrering - (DK) Genkalibrering